



MODEM PERIPHERAL DEVICE

CVM-COM-RED

(Code 7 70 228 - 7 70 229)

USER'S MANUAL

(M 981 319 / 01 A)

(c) CIRCUTOR S.A.

CVM-COM MANUAL CONTENTS	Page
1.- BASIC INSTRUCTIONS.....	2
1.1.- Checking the contents of your package.....	2
1.2.- Safety warnings.....	2
2.- CVM-COM-RED PERIPHERAL.....	3
3.- INSTALLATION AND STARTUP.....	4
3.1.- Connection procedure.....	5
3.2.- CVM-COM-RED connection terminals.....	6
3.3.- CVM-COM-RED connection mode (to a panel mounting CVM unit of CVMk type).....	8
3.4.- CVM-COM-RED connection mode (to a DIN rail mounting CVM unit).....	9
3.5.- Lighting indications of the CVM-COM-RED.....	10
3.6.- CVM-COM-RED push-buttons.....	10
4.- SETUP CONFIGURATION: CONNECTION INSTRUCTIONS.....	11
5.- TECHNICAL SPECIFICATIONS.....	12
6.- SAFETY CONSIDERATIONS.....	13
7.- MAINTENANCE.....	14
8.- TECHNICAL SERVICE.....	14
APPENDIX A.- CVM-COM-RED COMMUNICATIONS.....	15
A.1.- DEMAND FORMAT.....	15
A.2.- COMMANDS.....	16
A.2.1.- SETTING COMMANDS.....	16
A.2.2.- COMMANDS FOR THE CVMk PARAMETER READOUT.....	24
A.2.3.- COMMAND TO READ ALL PARAMETERS FROM THE CVMk.....	25
A.2.4.- ADDITIONAL COMMUNICATION COMMANDS FOR THREE BILLING PERIODS (CVM / RED-MAX MODULE).....	26
APPENDIX B.- USING A TERMINAL EMULATING SOFTWARE.....	27

CVM-COM-RED PERIPHERAL

1.- BASIC INSTRUCTIONS

1.1.- Checking the contents of your package

This manual is issued to help all the **CVM-COM-RED** peripheral users to install and apply it in order to get the best from it. After receiving the unit please check following points:

- (a) The delivered material meets your order specifications.
- (b) After unpacking, check that the instrument has not been damaged in transit.
- (c) The standard set includes a user's manual.


1.2.- Safety warnings



The manual you hold in your hands contains information and warnings about the **CVM-COM-RED** that the user should respect in order to guarantee a proper operation of all the instrument functions and keep its safety conditions.

2.- CVM-COM-RED PERIPHERAL

The **CVM CO WITH BUILT-IN MODEM** has the capacity of communicating with a 485 type network formed by CVM, CVM-M or other peripheral units.



The structure consists of the following features

- a.- RS-232 communication via the phone line (Full duplex). This RS-232 port is connected to the phone line by a **RJ-11 connector**.
- b.- 2 voltage-free inputs.
- c.- COM1: RS-232 serial port for a direct link to the PC.
- d.- COM2: RS-485 serial port for a link to the CVM family meters.

Description

The **CVM-COM-RED** is an instrument that permits the control of a 485 communication network via the phone line.

Main features of this instrument are below listed:

- Ability of controlling a 485 communication network from a remote site (via the phone line).
- Setting up actions over remote metering units.
- Downloading data from analyzers equipped with internal memory.
- Detection of alarms through its voltage-free inputs.
- Automatic call up when alarm conditions are met, so sending a user-programmable message.

3.- INSTALLATION AND STARTUP



The manual you hold in your hands contains information and warnings that the user should respect in order to guarantee a proper operation of all the instrument functions and keep its safety conditions.

The instrument must not be powered and used until its definitive assembly inside the switchgear board.

If the instrument is not used as manufacturer's specifications, the protection of the instrument can be damaged.

When any protection failure is suspected to exist (for example, it presents external visible damages), the instrument must be immediately powered OFF. In this case contact a qualified service representative.

3.1.- Connection procedure

Before powering the instrument up, please check following points:

(a) **Power supply:** 230 V~ (+ 10 % / - 15 %) between terminals marked as A1 - A2 (1 & 28).

(b) Frequency : 50 ... 60 Hz

(c) Instrument burden: 7 VA

(d) Operation conditions:

- Operation temperature : 0 to 50 °C

- Operation humidity : 75 % RH

(e) Safety: Designed to meet protection class II as per EN 61010.




Assembly mode:

The Instrument is to be mounted onto DIN rail. All connections keep inside the switchgear cabinet.

Notice that with the instrument powered on, the terminals could be dangerous to touching and cover opening actions or element removal may allow the access to dangerous parts. The instrument must not be used until this is completely installed.


The instrument must be connected to a power supply circuit protected with gI type (IEC 269) or M type fuses rated between 0.5 and 2 A. This circuit should be provided with a circuit breaker (I / O) or any equivalent element to connect (ON) or disconnect (OFF) the instrument from the power supply network, this switching element should be placed close to the instrument and be easily accessible. The power supply circuit will be connected through a wire with a minimum cross-section of 1 mm².

3.2.- CVM-COM-RED connection terminals




Te a o	a g	Co cept
1 - 28	A1 - A2	Power supply at 230 V~
23 24 25	GND 1 2	Common of voltage-free inputs Input of alarm No. 1 Input of alarm No. 2
20 - 19	Ending resistor (RT)	240 Ω resistor: for the adaptation of line end impedance. (bridge between terminals 20 -- 18 and 19 -- 17)
18 17 14	-- + GND	Connection to different peripherals in the 485 type network
5 6 7 8 9 10	DSR Tx Rx RTS CTS GND	<u>RS-232 connection to PC</u> Data set ready Transmitted data Received data Request to send Clear to send Common
11 to 13	PRINTER	Not in use


3.3.- CVM-COM-RED connection mode (to a panel mounting CVM unit of CVMk type)



3.4.- CVM-COM-RED connection mode (to a DIN rail mounting CVM unit)



3.5.- Lighting indications of the CVM-COM-RED



a.- "**CO**" LED: This led blinks when the peripheral is receiving data from the CVM ("Network") or from the PC. When no communication exists, then the led keeps off.

b.- "**C U**" LED: When it keeps on, it means that the CVM-COM-RED is running.

c.- Each lead indicates a particular modem operation status:

- "**C**": Indication of Data Carrier Detect
- "**S**": Indication of data sending process
- "": Indication of data reception process (some commands are being sent to the modem)

3.6.- CVM-COM-RED push-buttons

- **TEST**: This push-button permits the default configuration of the RS-232 serial port to be set in the CVM-COM-RED:

Peripheral 99 / 9.600 baud / 8 bits / 1 stop bit / Non

4.- SETUP CONFIGURATION: CONNECTION INSTRUCTIONS

- Connect the power supply of the instrument, 230 V a.c. (+ 10 % / - 15 %), to the terminals marked as A1 - A2 (1 and 28).

- Connect the RS-232 output of the CVM-COM to one of the serial ports of the PC unit, according to the below arrangement:

CVM -COM		←-----→	PC (DB-9)
DSR	Data set ready (5)		.
Tx	Transmitted data (6)	----->	2
Rx	Received data (7)	----->	3
RTS	Request to send (8)	----]	.
CTS	Clear to send (9)	----]	.
GND	Common (10)	----->	5

- SOFTWARE.

NOTE : If you do not know the configuration of the CVM-COM-RED, then proceed as follows: Remove the power supply from the CVM-COM. By pressing then the "T ST" button at the same time that it is again powered on, the RS-232 serial port of the CVM-COM is set with the following standard values:

Baud = 9.600 / Parity = NO / bits = 8 / Stop bits = 1 / peripheral = 99

5.- TECHNICAL SPECIFICATIONS**Power supply circuit:**

Voltage	Single-phase 230 V a.c.
Voltage tolerance	+10 % / -15 %
Frequency	50 ... 60 Hz
Burden	7 VA
Operation temperature	0 to 50 °C


Digital inputs	2 contact-type inputs
-----------------------------	-----------------------

Constructive characteristics

Case type	Modular type, self-extinguishing, plastic casing.
Connection terminals.....	Metallic terminals with "posidraft" screws
Assembly	To be fitted onto symmetric rail as per DIN 46277 (EN 50022) Screw fixing also possible (Ø 4,2 mm passing hole for fixing purposes)
Frontal cover	Lexan
IP degree	Built-in relay: IP 41 Terminals : IP 20
Dimensions	140 x 70 x 110 mm (8 module size as per DIN 43 880)
Safety	Class II, as per EN 61010

Standards	IEC 664, VDE 0110, UL 94
------------------	--------------------------

Dimensions :



6.- SAFETY CONSIDERATIONS



The user should take into account all installation instructions indicated in sections **INSTALLATION & STARTUP**, **CONNECTION PROCEDURE** and **TECHNICAL SPECIFICATIONS** of this manual.

Notice that with the instrument powered on, the terminals could be dangerous to touching, and cover opening or element removal actions may allow the access to dangerous parts. The analyzer has been designed and tested to meet IEC 348 standard and is factory-shipped in proper operating conditions.

7.- MAINTENANCE

The CVM-COM-RED does not require any special maintenance. No adjustment, maintenance or repairing action should be done over the instrument open and powered and, should those actions are essential, high-qualified operators must perform them.

Before any adjustment, replacement, maintenance or repairing operation is carried out, the instrument must be totally disconnected from any power supply source.

When any protection failure is suspected to exist, the instrument must be immediately put out of service.

The design of the analyzer permits its quick replacement in case of failure.

8.- TECHNICAL SERVICE

For any inquiry about the instrument performance or If any failure happens, please contact to CIRCUTOR's technical service.

C C T O S A A f t e s a e s s e v c e
c / e p a t o , 9
08223 T ASSA
T e 34 93 5 9 00
f a x 34 93 5 9
a c e t a c c t o e s

APPENDIX A.- CVM-COM-RED COMMUNICATIONS

The **CVM-COM -RED** can be directly connected to a PC, either via RS-232 or via the telephone line.

IMPORTANT REMARK!:

We must remark that the communication parameter setting for the RS-232 and the RS-485 must be totally identical, otherwise, the answer for the communication command will be an error.

In terms of the network of instruments connected to the RS-485 the situation is alike, that is, all communication parameters must be equal for all the units (excepts for the peripheral no.).

When the network is inquired with the identification code (peripheral no). 00, then the command will not be transferred to the network but only the CVM-COM-RED will answer.

PROTOCOL: Question / Answer

A.1.- DEMAND FORMAT

The demand format is: **\$PPCCCAA... ch [LF]** (example = **\$01RVI76**)

The answer format is: **\$PPAA... ch [LF]**

\$	Any message starts with this symbol (ASCII- 36).
PP	The identification code (peripheral number) (01 to 99) for the portable the CVM unit (decimal- ASCII)
CCC	COMMAND
AA	ARGUMENT (Decimal- ASCII).
Ch	CHECK-SUM : Check-sum of all the elements forming the message. It is calculated by the decimal addition of all the previous bytes in ASCII and then translating the result into hexadecimal. Two digits are taken. example = \$01RVI --> 36 + 48 + 49 +82 + 86 + 73 =374 374 decimal or 176 hexad. CHECK-SUM = 76 ----> \$01RVI76 [LF]
[LF]	LINE FEED indicates the end of the message (ASCII 10).

A.2.- COMMANDS

A.2.1.- SETTING COMMANDS

COMMAND	CONCEPT	QUESTION	ANSWER
DEF	Write default parameters	\$pp DEF ch	\$PP ACK ch
RRS	Read communications (*)	\$pp RRS ch	\$pp 13 digits ch
WRS	Write communications (*)	\$pp 13 digits ch	\$PP ACK ch

(*) NOTE : The RRS / WRS command (communications):

- 2 digits peripheral number / 1 digit Parity / 1 digit length / 1 digit Stop bits/
- 4 digits Baud rate SERIAL RS-232 output / 4 digit Baud rate 2nd RS-485 output

COMMAND	CONCEPT	QUESTION	ANSWER
VER	Read CVM-COM version	\$pp VER ch	\$pp 4 digits ch
INI	Reset	\$pp INI ch	-----
RNR	Read number of rings	\$pp RNR ch	\$pp 2 dig + ch
WNR	Write number of rings	\$pp WNR 2 dig ch	\$pp ACK ch

- **Counters of alarm events.**

\$XXALA<CHK> (or #XXALA<Ctrl+j>)

The answer is:

\$XXyyyyzzzz<CHK> (or #XXyyyyzzzz<Ctrl+j>)

Where:

yyyy: Times that the alarm 1 has been activated.

zzzz: Times that the alarm 2 has been activated.

- Deleting alarm events counters:

\$XXCLAy<CHK> (or #XXCLAy<Ctrl+j>)

The answer is:

\$XXACK<CHK> (or #XXACK<Ctrl+j>)

Where:

y: it refers to the alarm events counter to be reset to zero.

- **Reading the digital input status.**

\$XXINP<CHK> (or #XXINP<Ctrl+j>)

The answer is:

\$XXyz<CHK> (or #XXyz<Ctrl+j>)

Where:

- y: Status of the digital input 1.
- z: Status of the digital input 2.

Remarks:

- 1) Alarm events counters will increase their value always that an alarm condition is detected, regardless the call is made or not.
- 2) Alarm events counters will be reset to zero if the user delete these counters by using the applicable communication command, but also, in case of oversize.
- 3) The maximum value allowable for any alarm events counter is 9999. Once this value is reached, then the counter will be automatically reset to zero.

SUMMARY OF SETTING COMMANDS

COMMAND	CONCEPT	QUESTION	ANSWER
ALi *	Set alarm calls	\$ppALi+60 digits ch	\$PP ACK ch
RAi *	Read alarm calls	\$pp RAi ch	\$pp 60 digits ch
PHO	Enable/Disable alarms	\$ppPHO+3 digits ch	\$PP ACK ch
WMIi*	Write alarm message	\$ppWMIi+30 digit ch	\$PP ACK ch
RMIi *	Read alarm message	\$ppRMIi	\$PP 30 digits ch
ALA	Counter of alarm events	\$ppALA	\$PP 8 digits ch
CLAi *	Delete counter of alarm events	\$ppCLAi	\$PP ACK ch
INP	Read digital input status	\$ppINPi	\$pp 2 digits ch

* "i" refers to the digital input no. (i=1 ⇒ alarm 1; i=2 ⇒ alarm 2)

A.2.2.- COMMANDS FOR THE CVMk PARAMETER READOUT

(*) negative energies only for the CVMk-4C unit (four-quadrant measurement)

COMMAND	CONCEPT	QUESTION	ANSWER	UNIT
RVI	Read V line-to-neutral INST	\$pp RVI ch	\$pp 4 x 9 digits ch	V
ROI	Read V line-to-line INST	\$pp ROI ch	\$pp 4 x 9 digits ch	V
RAI	Read Current INST	\$pp RAI ch	\$pp 4 x 9 digits ch	mA
RPI	Read Active power INST	\$pp RPI ch	\$pp 4 x 9 digits ch	W
RFI	Read PF INST	\$pp RFI ch	\$pp 4 x 3 digits ch	x 100
RWH (*)	Read active energy (positive, negative - in absolute value -)	\$pp RWH ch	\$pp 1 x 9 digits ch \$pp 2 x 9 digits ch	Wh
RLH (*)	Read inductive energy (positive, negative - in absolute value -)	\$pp RLH ch	\$pp 1 x 9 digits ch - For the CVMk-4C: \$pp 2 x 9 digits ch	varLh
RCH (*)	Read capacitive energy (positive, negative - in absolute value -)	\$pp RCH ch	\$pp 1 x 9 digits ch - For the CVMk-4C: \$pp 2 x 9 digits ch	varCh
RCL	Read clock in real time dd/mm/yy hh:mm:ss	\$pp RCL ch	\$pp 17 characters ch	
RMD	Read maximum demand value: DATE, MAXIMUM (from the last reset), LAST PERIOD MAXIMUM	\$pp RMD ch	\$pp 35 digits ch xx/xx/xx xx:xx:xx + 9 dig + 9 dig	
CMD	Delete maximum demand value pd = 0	\$pp CMD ch	\$pp ACK ch	

A.2.3.- COMMAND TO READ ALL PARAMETERS FROM THE CVMk

COMMAND	CONCEPT	QUESTION	ANSWER SIZE
RAL	Read TOTAL	\$pp RAL ch	\$pp + 244 bytes + ch

With this parameter all the parameters are inquired: 30 x 8 bytes in hexa-ASCII format in the following order:

[0] L1	[1] L2	[2] L3	[3] M	Voltage line-to-line
[4] L1	[5] L2	[6] L3	[7] M	Voltage line-to-neutral
[8] L1	[9] L2	[10] L3	[11] M	Current
[12] L1	[13] L2	[14] L3	[15] III	Active power
[16] L1	[17] L2	[18] L3	[19] III	Inductive power
[20] L1	[21] L2	[22] L3	[23] III	Capacitive power
[24] L1	[25] L2	[26] L3	[27] M	Power factor (*)
			[28]	Frequency
			[29] III	Apparent power

- 2 bytes: current units 00 - mA / 01 - A
- 2 bytes: power units 00 - W / 01 - kW

(*) - Power factor (x 100): When capacitive then 200 is added

0 ----- 100 ----- 200
 +0.0 Ind 1.0 Cap - 0.0

A.2.4.- ADDITIONAL COMMUNICATION COMMANDS FOR THREE BILLING PERIODS (CVM / RED-MAX MODULE)

(*) negative energies only for the CVMk-4C unit (four-quadrant measurement).

COMMAND	CONCEPT	QUESTION	ANSWER	UNIT
RWHXn (*)	Read active energy (positive, negative - in absolute value -)	\$pp RWHXn ch	\$pp a x 9 digits ch \$pp 2a x 9 dig ch	Wh
RLHXn (*)	Read inductive energy (positive, negative - in absolute value -)	\$pp RLHXn ch	\$pp a x 9 digits ch - For the CVMk-4C : \$pp 2a x 9 dig. ch	varLh
RCHXn (*)	Read capacitive energy (positive, negative - in absolute value -)	\$pp RCHXn ch	\$pp a x 9 digits ch - For the CVMk-4C : \$pp 2a x 9 dig. ch	varCh
CMDXn	Delete maximum demand value pd=0	\$pp CMDXn ch	\$pp ACK ch	
RMDXn	Read maximum demand value: DATE, MAXIMUM (from the last reset), LAST PERIOD MAXIMUM	\$pp RMDXn ch	\$pp a x 35 digits ch xx/xx/xx xx:xx:xx xxxxxxxxxx (9 dig) xxxxxxxxxx (9 dig)	

 - "n" is the inquired tariff number:

- 0 ----- Tariff 1**
- 1 ----- Tariff 2**
- 2 ----- Tariff 3**
- 3 ----- All three tariffs**

Example: to inquire all three kWh counters:

\$00RWHX3 [ch] [LF]

- where "a" set the size of the answer:
 a= 1 if n= 0, 1 or 2
 a = 3 if n= 3

APPENDIX B .- USING A TERMINAL EMULATING SOFTWARE

- Setting communication with the CVM-COM-RED:

- Set the local serial port of the PC up with the same parameters set in the modem at the other side of the phone line.
- Enter the calling command ATD<phone number of the CVM-COM-RED><Cr>
(Cr: carriage return)
- Wait for a CONNECT message on the screen, coming from the modem. When this message appears, commands of the CVM-COM-RED can then be entered.
- Active the local echo to see all data being sent to the CVM-COM-RED: Select the echo option.

- To set the communication:

- A < Ctrl + J > message (press the J key simultaneously with the Ctrl one) is sent to the CVM-COM-RED peripheral.
- The demand format is: **#PPCCCAA**< Ctrl + J >.

All commands start with #PP, where PP stands for the identification code (peripheral number). CCC = COMMAND and AA = argument.

OT : Whether the peripheral number is not known, then the command can be sent with the identification code 00, since for the CVM-COM-RED only exists one remote peripheral.

- The answer format is: **#PPAA... CRLF**

The commands with this special character # which are allowed are only those that do not modify any critical parameter of the SETUP. In this case, the instrument does not check the check-sum. The answer always ends in CRLF to make easier its visualization.

- **Freeing the communication with the peripheral:**

To end the communication is necessary to free the line; to do that act as follows:

- Active the command mode in the local modem.

Type +++ (three "+" characters). After few seconds, the message 'OK', coming from the modem, should appear on display. This indicates that the this modem will be the receiver of the commands from now on. Whether 'OK' does not appear, then it will automatically try it again.

- Unable the local echo or, otherwise, all characters typed from now on will be doubly displayed. Deselect the option > Echo .

- Hung the line up by typing the modem command ATH<Cr>.

The led "CD" in the CVM-COM will be off. The modem will answer an 'OK' message.